# **Project Documentation**

Diagnostic Rev. 586220 Harness - Keyboard Dongle

Project number: 116

Revision: 0

Date: 28.02.2019

## Diagnostic Rev. 586220 Harness - Cassette Port Rev. 0

# Module Description

This PCB is a part of the harness for the Diagnostic Rev. 586220 test software for the Commodore C64.

The cassette port PCB connects to the cassette port of the C64 and provides the signal on a 2x3 pin header, which is connected to the central component of the Diagnostic Rev. 586220 harness, the user port PCB.

### Pin outs

### Cassette Port

J1 – 2 x 6p edge connector (pitch 3.96mm)

Pin	Signal	Pin	Signal
1	GND	Α	GND
2	+5V	В	+5V
3	MOTOR	С	MOTOR
4	READ	D	READ
5	WRITE	Е	WRITE
6	SENSE	F	SENSE


### Harness Connector

J2 – 2x3p Pin Header (pitch 2.54mm)


Pin	Signal	Pin	Signal
1	GND	2	+5V
3	MOTOR	4	READ
5	WRITE	6	SENSE

02.03.2019 12:14


Doc.-No.: 114-6-01-00




Diag 586220	DocNo.: 1	14-2-01-00
Harness	<b>Cu:</b> 35µm	Cu-Layers: 2
Diag_586220_Cass	ette	
01.03.2019 11:20		Rev.: 0
placement component	side	




Diag 586220	DocNo.: 1	14-2-01-00
Harness	<b>Cu:</b> 35µm	Cu-Layers: 2
Diag_586220_Cass	ette	
01.03.2019 11:20		Rev.: 0
placement component	side	




Diag 586220	DocNo.: 1	14-2-01-00
Harness	<b>Cu:</b> 35µm	Cu-Layers: 2
Diag_586220_Cass	ette	
01.03.2019 11:20		Rev.: 0
top		




Diag 586220	DocNo.: 1	14-2-01-00
Harness	<b>Cu:</b> 35µm	Cu-Layers: 2
Diag_586220_Cass	ette	
01.03.2019 11:20		Rev.: 0
bottom		




Diag 586220	DocNo.: 1	14-2-01-00
Harness	<b>Cu:</b> 35µm	Cu-Layers: 2
Diag_586220_Cass	ette	
01.03.2019 11:20		Rev.: 0
stopmask component	side	



Diag 586220	DocNo.: 1	14-2-01-00
Harness	<b>Cu:</b> 35µm	Cu-Layers: 2
Diag_586220_Cass	ette	
01.03.2019 11:20		Rev.: 0
stopmask solder side		



Diag 586220	DocNo.: 1	14-2-01-00
Harness	<b>Cu:</b> 35µm	Cu-Layers: 2
Diag_586220_Casso	ette	
01.03.2019 11:20		Rev.: 0
placement component	side mea	sures



# Diagnostic Rev. 586220 Harness - Cassette Port Rev. 0 Bill of Material Rev. 0.0

		_		
Pos.	Qty Value	Footprint	RefNo.	Comment
_	1 114-2-01-00	2 Layer	PCB Rev. 0	2 layer, Cu 35µ, HASL, 30.0mm × 25.0mm, 1.6mm FR4
2	1 2x6, 3.96mm pitch	C64-TAPEPORT	JJ	edge connector, C64 cassette port
က	1 2x3 box connector	2X03WV	J2	e.g. Reichelt WSL 6G
4	1 3mm/green	3MM	LD1	LED, 3mm, green
5	1 330R	RESO1	R1	1/4 Watt, 5%